

FIRE ALARMS - DORMS

(09/09/05)

- BENTON:** Does not reset itself. The panel is in the equipment room. Silence the panel, reset the station, put the silence switch back to normal. The panel will be reset.
- BENTON NORTH:** Does not reset itself. The panel is under the utility room in the center stairwell. The handle for the trap door is in the porch in Carol Hall. Silence the panel, reset the station, and reset the panel.
- CAROL HALL:** Runs for four minutes and stops. Trouble bell then rings. After the problem is solved, reset the bi-metal strip inside the panel. The system is reset if no alarm resounds. If the problem is not found and corrected, the whole building is without a fire alarm system. The panel is on the porch.
- GARVEY:** Does not reset itself. The panel is in the 1st floor office. Silence the alarm, reset the station, and reset the panel. When testing flow switches, acknowledge alarms, use the reset only when done with all flow testing.
- HILL-CASE:** Does not reset itself. The panel is in the center equipment room. Silence the panel, reset the station, and reset the panel.
- HOLES:** Does not reset itself. The panel is in the basement equipment room. Silence the alarm, reset the station and reset the panel.
- LAWRENCE HALL:** Does not reset itself. The panel is located in Basement mechanical Room #A07. Push alarm acknowledge button. Read LED display to learn location of problem. Verify problem, silence only if there is no threat to life or property. Fix problem then reset panel.
- MITCHELL:** Does not reset itself. The panel is located in Basement electrical room #49. Push alarm acknowledge button. Read LED display to learn location of problem. Verify problem, silence only if there is no threat to life or property. Fix problem then reset panel.
- SHERBURNE:** Does not reset itself. Panel is behind front desk. Push alarm acknowledge button. Read LED display to learn location of problem. Verify problem, silence only if there is no threat to life or property. Fix problem then reset panel.
- SHOEMAKER (NEW):** Does not reset itself. The panel is in West Shoe basement elevator room. Silence the alarm, reset the station, and reset the panel.
- SHOEMAKER NORTH:** The building is several zones in the panel for New Shoemaker which is located in the basement elevator room of West Shoemaker Hall. If dry system is the cause of the alarm, Maintenance Dept. must be called.
- STEARNS:** Does not reset itself. The panel is in basement equipment room. Silence the alarm, reset the station, and reset the panel.